Marlboro Music

Magnetic Care and Information

TO PROPERLY CARE FOR AND UNDERSTAND THE USE OF THESE SIGNS **YOU MUST READ THROUGH THIS ENTIRE DOCUMENT BEFORE PROCEEDING WITH UNPACKING OR USING THESE SIGNS.** IF YOU HAVE ANY QUESTIONS OR DO NOT UNDERSTAND ANY OF THESE INSTRUCTIONS, PLEASE CALL US **IMMEDIATELY!** ASK FOR ROB OR WENDY.

DECAL APPLICATION SERVICES, INC.
1-800-451-4148

REMEMBER TO SAVE THIS DOCUMENT AND TO PACKAGE IT WITH THE SIGNS IN THE ORIGINAL BOX SO THAT WHEN YOU SHIP THESE SIGNS TO THE NEXT LOCATION, THE PERSON ON THAT END CAN FOLLOW THESE PROCEDURES ALSO!!!!!

UNPACKING

OPEN BOX CAREFULLY, USE A KNIFE TO CUT THE TAPE SO THAT YOU CAN REUSE THE BOX FOR STORAGE AND SHIPPING OF THIS FINE MAGNETIC SIGN. DO NOT DAMAGE, DESTROY OR MISPLACE THE BOX. AFTER OPENING THE BOX CAREFULLY SLIDE OUT THE BAG WITH THE SIGN IN IT. LOOSEN THE TIE ON ONE END OF THE BAG. CAREFULLY SLIDE OUT THE SIGN. THE SIGN IS ROLLED AROUND A CARDBOARD CORE TO KEEP IT FROM GETTING CREASED. CAREFULLY UNROLL THE SIGN ON A CLEAN SURFACE. SAVE THE PAPEF LINER THAT IS ROLLED UP WITH THE SIGN TO USE FOR STORAGE AND SHIPPING LATER.

PREPARATION

PREPARE THE SURFACE OF THE VEHICLE BY CLEANING, DRYING AND WAXING IT (WAX RIGHT OVER THE ENTIRE DECALS TO BE COVERED UP WITH A GOOD AUTOMOTIVE WAX). FAILURE TO COMPLETE THIS STEP MAY RESULT IN LOWERED ADHESION AND MAY CAUSE THE SIGN TO BLOW OFF AT HIGH SPEEDS!!!!!!!!

PREPARE THE BROWN MAGNETIC SIDE OF THE SIGN BY CLEANING AND DRYING IT. TO CLEAN THE SIGN AND THE VEHICLE USE A MILD DETERGENT IN WARM WATER. BE SURE TO WIPE IT DRY. INSPECT BOTH THE SIGN AND THE VEHICLE FOR ANY DIRT OR PARTICLES YOU MAY HAVE MISSED BEFORE APPLYING THE MAGNETIC SIGN.

2041915044

TEMPERATURE

Source: https://www.industrydocuments.ucsf.edu/docs/mxpn0004

THE TEMPERATURE OF THE VEHICLE IS UNIMPORTANT; HOWEVERE SIGN SHOULD BE AT LEAST 60 DEGREES F FOR INSTALLATION.

APPLICATION

PLACE ONE EDGE OF THE SIGN AT THE DESIGNATED AREA...

(TO COVER UP THE HOOD DECALINE IT UP WITH THE TOP TWO CORNERS ALLOWING THE WARNING AND PRESENTED BY... TO SHOW AT THE BOTTOM)

OR

(TO COVER UP THE TAILGATE DECALINE UP THE HOLE CUT OUT FOR THE HANDLE SO THAT IT IS CENTERED AROUND THE HANDLE AND THE BOTTOM EDGE OF THE MAGNETIC LINES UP WITH THE BOTTOM OF THE TAILGATE)

ALLOW THE REMAINDER OF THE SIGN TO CONTACT THE SURFACE.THE ALIGNMENT IS INCORRECT, REMOVE AND REPOSITION. TO AVOID STRETCHING OR TEARING THE SIGN, DO NOT STRAIGHTEN THE SIGN BY PULLING WHEN IT IS MAGNETICALLY AFFIXED TO THE VEHICLE.

ONCE THE SIGN IS IN POSITION CHECK TO MAKE SURE THAT IT IS SMOOTH AND FLAT ON THE SURFACE WITH NO OPENINGS OR AIR GAPS (THE WIND WILL SURELY BLOW IT OFF IF THERE IS A PLACE FOR IT TO GET UNDER THE SIGN!!!!).

THE SIGN SHOULD BE EITHERON THE VEHICLE OR REPACKAGED IN THE SAME MANNER IT LEFT OUR FACILITY FOR STORAGE OR SHIPPING TO ANOTHER LOCATION. THERE IS NO REASON FOR IT TO BE ANYWHERE ELSE!!!!!

REPACKAGING

LAYOUT THE PAPER LINER ON A FLAT SURFACEGLOSSY SIDE DOWN. MAKE SURE IT IS CLEAN AND FREE OF DIRT OR PARTICLES.

GENTLY WIPE CLEAN BOTH SIDES OF THE MAGNETIC SIGN AND DRY IT THOROUGHLY.

LAY THE SIGN ON THE PAPER LINER BROWN SIDE UP SO THAT IT ISCENTERED ON THE PAPER LINER.

LAY THE CARDBOARD CORE ACROSS THE SIGN AT ONE END AND IN A WAYS FROM THE END.

CAREFULLY PICK UP THE PAPER AND THE SIGN TOGETHER AND BEGIN ROLLING THEM ON THE CORESMOOTHLY AND AS STRAIGHT AS POSSIBLE (SO THAT THE OUTSIDE EDGES STAY LINED UP).

2041915045

Source: https://www.industrydocuments.ucsf.edu/docs/mxpn0004

ONCE THE SIGN AND PAPER ARE COMPLETELY ROLLED ONTO THE CORE CAREFULLY WRAP A PIECE OF TAPE AROUND THE OUTSIDE OF THE LINER TO KEEP IT FROM COMING LOOSE.

INSERT THE SIGN ROLLED ONTO THE CORE AND PAPER LINER INTO THE PLASTIC BAG PROVIDED. USE THE BAG TIE PROVIDED TO CLOSE THE OPEN END OF THE BAG TO PREVENT DUST AND MOISTURE FROM DAMAGING THE SIGN DURING STORAGE AND / OR SHIPPING. BE SURE AND LEAVE ENOUGH SLACK AT EACH END OF THE BAG SO IT CAN BE PUSHED INSIDE THE CORE A LITTLE WAYS.

PLACE THE SIGN IN THE BAG INTO ITS ORIGINAL SHIPPING CONTAINER (BOX). NOTE THAT THE CORE WILL BE HELD IN THE CENTER OF THE BOX AT EACH END BY THE BOX ITSELF. THIS PREVENTS THE SIGN FROM RUBBING UP AGAINST THE INSIDE OF THE BOX.

TAPE THE BOX CLOSED IN A MANNER THAT WILL ALLOW YOU OR SOMEONE ELSE TO OPEN IT WITHOUT DAMAGING THE BOX.

2041915045

Source: https://www.industrydocuments.ucsf.edu/docs/mxpn0004